

Checklist for taking apart solar cars:

Be careful!

1. Stay at your table and work as a team to complete these steps
2. All parts will be returned to the bins on the front counter
3. Use your checkout sheet to double-check the parts you should have
4. Bring the loose parts up in your box so you can walk down the line and put in the appropriate tub

Axles and Wheels

- Take off axles—work at removing as much glue as you can
- Take wheels off the axles using a pliers as necessary

Gears

- Remove gears from motor and axles—use pliers or wire strippers as necessary
- Remove as much glue as you can from gears

Motor and Battery Pack

- Unbundle alligator clips (save rubber band)
- Pry motor off and remove as much glue as you can
- Remove battery pack—it is okay if there is Velcro still stuck on the battery pack

Shoebox

- Remove the label from the end of box and place in trash
- After you deliver your parts to the front we will stack shoeboxes (nestling as much as possible)

Your yellow packet should be turned into the basket!